


Panel Builder 3 Condor



Chronometer Condor

Displays Local Time in a Chronometer (time only!)



Clock Analog Condor

Displays Local Time in Clock Dial format.



Com Radio Condor

Displays frequency of the Com Radio



Magnetic Compass

Displays the magnetic heading of the aircraft



Airspeed Indicator Antares 18S

Displays airspeed in km/h



Airspeed Indicator Condor Blanik

Displays airspeed in km/h



Airspeed Indicator Condor Cirrus

Displays airspeed in km/h



Airspeed Indicator Condor Diana 2

Displays airspeed in km/h



Airspeed Indicator Condor Duo Discus

Displays airspeed in km/h

Panel Builder 3 Condor



Airspeed Indicator Condor Duo Discus Knots

Displays airspeed in knots



Airspeed Indicator Condor Genesis 2

Displays airspeed in km/h



Airspeed Indicator Condor Grunau Baby

Displays airspeed in km/h



Airspeed Indicator Km/h

Displays airspeed in Km/h



Airspeed Indicator knots

Displays airspeed in knots



Airspeed Indicator knots (reversed)

Displays airspeed in knots



Airspeed Indicator Condor LS8 Neo

Displays airspeed in km/h



Airspeed Indicator Condor SG 38

Displays airspeed in km/h



Airspeed Indicator Condor Swift S1

Displays airspeed in km/h

Panel Builder 3 Condor



Airspeed Indicator Condor Ventus 3-15

Displays airspeed in km/h



Altimeter Condor

Displays altitude in feet



Artificial Horizon Condor

Displays the attitude of aircraft



EVariometer Condor

Displays vertical speed and altitude



GForce Condor

Displays the G-Force exerted on the aircraft



Heading Indicator Condor

Displays the current heading



Turn Rate and Slip Indicator for Condor

Displays the turn rate in deg/min and if the aircraft slips (is uncoordinated).



Variometer Condor

Displays the rate at which the aircraft climbs or descends in knots or meters/second

Yaw String Condor



Displays the a yaw string overlay on the main monitor