



Clock/Chronometer Gazelle

Clock with Chronometer functions



Warning Panel Gazelle

Displays various warnings and system information




Volts of Battery

Displays Volts for the Battery



Engine Temperature

Displays Engine Temperature in hundreds of Deg C



Oil Temperature of Engine

Displays Oil Temperature of Engine in Deg C



Rotor and Turbine RPM

Displays RPM of Rotor and Turbine



Torque of Helicopter Engine

Displays the torque of the helicopter engine in percent



Fuel Tank

Displays Fuel available in tenths of liters



Heading, ADF and NADIR/VOR display

Displays the direction to current ADF and NADIR/VOR and magnetic heading (slaved to Gyro)



Airspeed Indicator for Gazelle

Displays airspeed in km/h



Altimeter with Barometric Pressure adjustment

Displays altitude in meters



Artificial Horizon Gazelle

Displays attitude of helicopter



Artificial Horizon Gazelle (Standby)

Displays attitude of helicopter



Radio Altimeter with Decision Height Bug

Displays altitude in meters above ground level. Ability to set decision height with lit LED when decision height is reached.



Vertical Speed Indicator Gazelle

Displays the rate at which the helicopter climbs or descends in hundreds of meters per minute