

Panel Builder 3 - Spitfire



Analog Clock Spitfire

Displays an Analog Clock



Gear Position Indicator Spitfire

Displays Positon of Landing Gear



Oxygen Pressure Spitfire

Displays the Oxygene Pressure




Oxygen Tank Spitfire

Displays the level of the Oxygen Tank



Trim Indicator Spitfire

Displays Positon of the Elevator Trim



Voltage of Battery

Displays Voltage for Battery



Boost Gauge Spitfire (alternate version)

Show boost pressure



Boost Gauge Spitfire (alternate version)


Show boost pressure



Boost Gauge Spitfire

Show boost pressure

Panel Builder 3 - Spitfire



Oil Pressure Spitfire

Displays the oil pressure



Oil Temperature Spitfire

Displays the oil temperature in Deg C



Radiator Temperature Spitfire

Displays the radiator temperature in Deg C



RPM of Engine

Displays the RPM of the engine



RPM of Engine

Displays the RPM of the engine



Fuel Spitfire

Displays current available fuel quantity in gallons



Fuel Tanks Inner Mosquito

Displays the level of the inner fuel tanks



Fuel Tank Main Mosquito

Displays the level of the main fuel tank



Fuel Tanks Outer Mosquito

Displays the level of the outer fuel tanks

Panel Builder 3 - Spitfire



Airspeed Indicator Spitfire Knots

Displays airspeed in miles per hour



Altimeter with Barometric Pressure adjustment Spitfire

Displays altitude in feet



Artificial Horizon Spitfire

Displays attitude of aircraft



Directional Gyro Spitfire

Displays aircraft heading



Turn Rate and Slip Indicator Spitfire

Displays the turn rate in deg/min and if the aircraft slips (is uncoordinated).



Vertical Speed Indicator Spitfire

Displays the rate at which the aircraft climbs or descends in feet/minute