

Panel Builder 3 - Instruments Standard Six



Airspeed Indicator with speed ranges (configurable)

Displays airspeed in knots



Altimeter with Barometric Pressure adjustment

Displays altitude in feet



Artificial Horizon

Displays attitude of aircraft



Heading Indicator Magnetic

Displays the current heading with bug for autopilot



Turn Rate and Slip Indicator

Displays the turn rate in deg/min and if the aircraft slips (is uncoordinated).



Vertical Speed Indicator

Displays the rate at which the aircraft climbs or descends in feet/minute